

CARE & MAINTENANCE

Textiles

Vacuum fabric as needed using an upholstery attachment to remove dust or dirt. Do not use a fabric brush or rotary brush attachment.

Dry-clean or spot clean with solvent cleaner if further cleaning is required.

Leather

Dust with a dry or slightly damp lint free cloth. Gently wipe with a damp sponge with special detergent and then dry with a lint-free cloth. Avoid leaving leather in direct sunlight for long periods of time.

Metal Surfaces

Aluminum surfaces should be cleaned with a dry cloth or nonferrous metal detergents.

Powder coat metal surfaces should be cleaned with a damp cloth and dried with a lint-free cloth. A water-dampened cloth and mild, non-detergent soap can also be used. Rinse with a water-dampened cloth and dry thoroughly.

Plastic Surfaces

Clean plastic surfaces with a water-dampened cloth. Dry thoroughly with a lint-free cloth.

Laminate Surfaces

Use a damp cloth or sponge and a mild soap or detergent. Rinse thoroughly with warm water and wipe dry.

Please refer to the Wilsonart website for cleaning instructions to clean specific types of stains:
https://www.wilsonart.com/media/Technical_Resources/en/hpl_cm.pdf